

# SECTION 6

# ENGINE

## CONTENTS

<u>SUBJECT</u>	<u>PAGE</u>
Engine .....	6-1
General Information .....	6-1
Engine, Driveability, And Diagnosis .....	6A-1
4.3L V6 .....	6A3-1
5.0L And 5.7L V8 .....	6A4-1
7.4L V8 .....	6A5-1
6.5L Diesel .....	6A6-1
Engine Cooling .....	6B1-1
Radiator .....	6B2-1
Fuel System .....	6C-1
Diesel Fuel Injection .....	6C2-1
Engine Electrical .....	6D-1
Battery .....	6D1-1
Cranking System .....	6D2-1
Charging System .....	6D3-1
Ignition System .....	6D4-1
Engine Wiring .....	6D5-1
Diesel Glow Plug Electrical System .....	6D6-1
Emissions .....	6E-1
Diesel Emissions .....	6E2-1
Exhaust System .....	6F-1
Vacuum Pump .....	6H-1
Turbocharger .....	6J-1

## GENERAL INFORMATION

Following are brief outlines of the information contained in SECTION 6. Use them as a guide to help locate information quickly.

Detailed repair information on components such as oil pump, cylinder head, etc. is not included. Refer to the Light Duty Truck Unit Repair Manual for this information.

### SECTION 6A ENGINE, DRIVEABILITY, AND DIAGNOSIS

This section contains information common to all engines, including:

- Use of gasket sealers
- Diagnosis (for engine mechanical)
- Compression check procedure
- Oil leak diagnosis

### SECTIONS 6A3 THROUGH 6A6

### 4.3L V6, 5.0L AND 5.7L V8, 7.4L V8, AND 6.5L DIESEL

These sections contain information for on-vehicle servicing of the basic engine, such as manifold, cylinder head, camshaft, and piston replacement.

### SECTION 6B1 ENGINE COOLING

This section has information on cooling system components, including:

- Diagnosis
- Coolant Pump
- Fan and Fan Clutch
- Auxiliary Fan
- Belt
- Thermostat

### SECTION 6B2 RADIATOR

This section contains information on radiators and shrouds, including aluminum radiator repair procedures.

## **6-2 ENGINE**

---

### **SECTION 6C FUEL SYSTEM**

This section contains information on diesel engine fuel system components, including:

- Accelerator controls
- Fuel tanks
- Air cleaners

For information on gasoline engine fuel systems and diesel engines with electronic engine controls (ECM). Refer to the Driveability, Emissions, and Electrical Diagnosis Manual.

### **SECTION 6C2 DIESEL FUEL INJECTION**

This section contains information on the mechanical fuel injection system used on some diesel engines, including:

- Timing adjustment and other adjustment procedures.
- Injection nozzle replacement and testing.
- Injection pump replacement and repairs.

For information on diesel engines with electronically controlled fuel injection systems, refer to the Driveability, Emissions, and Electrical Diagnosis Manual.

### **SECTION 6D ENGINE ELECTRICAL**

This section contains information on electrical components associated with engine operation, including:

- Spark plug wires
- Battery
- Glow plug system
- Starters
- Generators
- Distributors
- Engine Wiring

On-vehicle service procedures are given. For overhaul information, refer to the Light Duty Truck Unit Repair Manual.

### **SECTION 6E EMISSIONS**

For information on throttle body fuel injection (TBI) emissions systems, refer to the Driveability, Emissions, and Electrical Diagnosis Manual.

### **SECTION 6E2 DIESEL EMISSIONS**

This section contains information on the emissions systems of diesel engines with mechanical injection pumps, including component repair. Driveability diagnosis can be found in SECTION 6A.

For diesel engines with electronically controlled injection pumps, refer to the Driveability, Emissions, and Electrical Diagnosis Manual.

### **SECTION 6F EXHAUST SYSTEM**

This section contains information on the exhaust system, including component replacement.

### **SECTION 6H VACUUM PUMPS**

This section contains information on vacuum pumps, including replacement procedures and diagnosis.

### **SECTION 6J TURBOCHARGER**

This section contains information on the diesel engine turbocharger, including diagnosis and component replacement.

For information on the diesel engine turbochargers with electronic controls (if equipped), refer to the Driveability, Emissions, and Electrical Diagnosis Manual.

**SECTION 6A**

**ENGINE, DRIVEABILITY, AND  
DIAGNOSIS**

**NOTICE:** Always use the correct fastener in the correct location. Use the correct fastener part number to replace a fastener. If the correct fastener part number is not available, a fastener of equal size and strength may be used. Do not use a fastener that is stronger when the correct fastener part number is not available in the following applications:

- Some bolts are designed to permanently stretch, and if a stronger fastener is used, the part will not be tightened correctly. These permanently stretching bolts will be called out. The correct part number fasteners must be used to replace this type of fastener because there is no available equivalent.
- Other bolts are designed to break if over tightened to prevent part damage. If a stronger fastener is used part damage may occur.

Fasteners that need to be replaced when removed will be called out. Fasteners that require thread lockers or thread sealant will be called out. The correct tightening specification and sequence must be used when installing fasteners. Part or system damage may occur if the above instructions are not followed.

**CONTENTS**

<b>SUBJECT</b>	<b>PAGE</b>
General Information .....	6A-2
Statement on Cleanliness and Care .....	6A-2
Tune-Up Information .....	6A-2
Use of RTV Sealer and Anaerobic Gasket Eliminator .....	6A-2
Using RTV Sealer .....	6A-2
Using Anaerobic Gasket Eliminator .....	6A-3
Replacing Engine Gaskets .....	6A-3
Compression/Cranking Speed Tests .....	6A-3
Gasoline Engine Compression Test .....	6A-3
6.5L Diesel Engine Compression Test .....	6A-3
Cranking Speed Test (6.5L Diesel Engine) .....	6A-4
Camshaft Gear Timing Test .....	6A-4
Diagnosis Charts .....	6A-5
Diesel Engine Diagnosis .....	6A-5
Diagnosis of "Service Fuel Filter" Light .....	6A-10
Diagnosis of Noises .....	6A-10
Diagnosis of Power Problems .....	6A-14
Diagnosis of Starting/Idling/Shutoff Problems .....	6A-15
Diagnosis of Poor Fuel Economy/Smoke/Oil/Odors .....	6A-18
Diagnosis of Spark Plugs .....	6A-20
Oil Leak Diagnosis .....	6A-20
Finding the Leak .....	6A-20
Repairing the Leak .....	6A-21
Special Tools .....	6A-21

### GENERAL INFORMATION

#### STATEMENT ON CLEANLINESS AND CARE

- An engine is a combination of many machined, honed, polished, and lapped surfaces with very fine tolerances.
- Whenever valve train components, cylinder head, cylinder block, crankshaft, or connecting rod components are removed for service, they should be retained in order. At the time of installation, they should be installed in the same locations and with the same mating surfaces as when removed.
- Any time the air cleaner or TBI unit is removed, the intake opening must be covered. If a diesel engine is being serviced, the recommended cover set (J 29664) should be used. This will protect against the entrance of foreign material which could follow the intake passage into the cylinder and cause extensive damage when the engine is started.
- When any internal engine parts are serviced, care and cleanliness are important. Apply a liberal coating of engine oil to friction areas during assembly to protect and lubricate the surfaces on initial operation. Throughout this section, it should be understood that proper cleaning and protection of machined surfaces and friction areas is part of the repair procedure. This is considered standard shop practice even if not specifically stated.
- On diesel engines, whenever the fuel injection pump or lines are removed or disconnected, take care to prevent the entry of dirt into the pump, lines, and injectors. The entry of even a small amount of dirt or other foreign material into the fuel injection system may cause serious damage.
- Keep in mind, while working on the engine, that the 12-volt electrical system is capable of violent and damaging short circuits. When performing any work where electrical terminals could possibly be grounded, disconnect the battery ground cable at the battery.
- Disconnect battery cables before any major work is performed on the engine. Failure to disconnect cables may result in damage to wire harness or other electrical parts.
- Cover or otherwise protect exposed electrical connections to prevent damage from oil and fuel.
- When raising and supporting the engine for any reason, do not use a jack under the oil pan. Due to the small clearance between the oil pan and oil pump screen, jacking against the oil pan may cause it to be bent against the pump screen resulting in a damaged oil pickup unit.

#### TUNE-UP INFORMATION

All information required to tune up the vehicle's engine is given in the Engine Emission Control Label located in the engine compartment.

Information that can be found on the label includes:

- Engine displacement.
- Timing specifications.
- Spark plug gap.

- Timing adjustment procedures.
- Emission hose routing.

#### USE OF RTV SEALER AND ANAEROBIC GASKET ELIMINATOR

Two types of sealer are commonly used in engines covered by this manual. These are RTV sealer and anaerobic "gasket eliminator" sealer.

It is important that these sealers be applied properly and in the proper place to prevent oil leaks. THE TWO TYPES OF SEALER ARE NOT INTERCHANGEABLE. Use the sealer recommended in the procedure.

- RTV (room temperature vulcanizing) sealer is used where a non-rigid part is assembled to a rigid part. Common examples are oil pans and rocker arm covers.
- Anaerobic gasket eliminator hardens in the absence of air. This sealer is used where two rigid parts (such as castings) are assembled together. When two rigid parts are disassembled and no sealer or gasket is readily noticeable, the parts were probably assembled using gasket eliminator.

#### USING RTV SEALER

1. Don't use RTV where extreme temperatures are expected, such as exhaust manifold, head gasket, or where gasket eliminator is specified.
2. When separating components sealed with RTV, use a rubber mallet and "bump" the part sideways to shear the RTV sealer. "Bumping" should be done at bends or reinforced areas to prevent distortion of parts. RTV is weaker in shear (lateral) strength than in tensile (vertical) strength.

**NOTICE:** Attempting to pry or pull components apart may cause damage to the part.

3. Surfaces to be resealed must be clean and dry. Remove all gasket material from the part using a plastic or wood scraper. Use Loctite brand "Chisel Gasket Remover" (P/N 79040), Permatex brand "Gasket Remover" (P/N 4MA) or equivalent. Follow all safety recommendations and directions that are on the can. Do not use any other method or technique to remove gasket material from a part. Do not use abrasive pads, sand paper, or power tools to clean gasket surfaces. These methods of cleaning can damage the part. Abrasive pads also produce a fine grit that the oil filter can not remove from the oil. This grit is abrasive and has been known to cause internal engine damage.
4. Apply RTV to one of the clean surfaces. Use a bead size as specified in the procedure. Run the bead to the inside of any bolt holes. Do not allow the sealer in any blind threaded holes, as it may prevent the bolt from seating properly or cause damage when the bolt is tightened.
5. Assemble while RTV is still wet (within 3 minutes). Don't wait for RTV to skin over.
6. Tighten bolts to specifications. Don't over-tighten.

## USING ANAEROBIC GASKET ELIMINATOR

1. Surfaces to be resealed must be clean and dry. Remove all gasket material from the part using a plastic or wood scraper. Use Loctite brand "Chisel Gasket Remover" (P/N 79040), Permatex brand "Gasket Remover" (P/N 4MA) or equivalent. Follow all safety recommendations and directions that are on the can. Do not use any other method or technique to remove gasket material from a part. Do not use abrasive pads, sand paper, or power tools to clean gasket surfaces. These methods of cleaning can damage the part. Abrasive pads also produce a fine grit that the oil filter can not remove from the oil. This grit is abrasive and has been known to cause internal engine damage.

2. Apply a continuous bead of gasket eliminator to one flange.
3. Spread bead evenly with your finger to get a uniform coating on the complete flange.
4. Assemble parts in the normal manner and tighten fasteners to specifications.

## REPLACING ENGINE GASKETS

**CAUTION:** Composite type gaskets are used in some areas of the engine assembly. These gaskets have a thin metal core. Use caution when removing or handling composite gaskets to help avoid personal injury.

# COMPRESSION/CRANKING SPEED TESTS

## GASOLINE ENGINE COMPRESSION TEST

1. Disconnect the primary lead from the distributor or ignition coil. Refer to SECTION 6D4.
2. Remove all spark plugs.
3. Block the throttle plate wide open.
4. Be sure the battery is fully charged.
5. Starting with the compression gage at zero, crank the engine through four compression strokes (four "puffs").
6. Perform the compression test at each cylinder and record each reading.
7. If some cylinders have low compression, inject about 15 ml (one tablespoon or about 3 squirts from a pump type oil can) of engine oil into the combustion chamber through the spark plug hole.
8. Minimum compression recorded in any one cylinder should not be less than 70 percent of highest cylinder, and no cylinder should read less than 690 kPa (100 psi). For example, if the highest pressure in any one cylinder is 1035 kPa (150 psi), the lowest allowable pressure for any other cylinder would be 725 kPa (105 psi). ( $1035 \times 70\% = 725$ ) ( $150 \times 70\% = 105$ ).

- Normal—Compression builds up quickly and evenly to specified compression in each cylinder.
- Piston Rings Leaking—Compression low on first stroke tends to build up on following strokes but does not reach normal. Improves considerably with addition of oil.
- Valves Leaking—Low on first stroke. Does not tend to build up on following strokes. Does not improve much with addition of oil.
- If two adjacent cylinders have lower than normal compression, and injecting oil into cylinders does not increase the compression, the cause may be a head gasket leak between the cylinders.

## 6.5L DIESEL ENGINE COMPRESSION TEST

Tools Required:

- J 29664 Cover Set
- J 26999 Compression Gage
- J 26999-10 Compression Gage Adapter

1. Remove the air cleaner. Cover the opening in the intake manifold with J 29664.
2. Disconnect the pink wire from the fuel solenoid terminal of the injection pump. Refer to figure 1.
3. Disconnect wires from glow plugs then remove all glow plugs.
4. Screw J 26999-10 into the glow plug hole of the cylinder that is being checked. Connect to J 26999 (figure 2).
5. Be sure the batteries are fully charged, and the engine is fully warmed up (engine oil hot).
6. Crank the engine. Allow six "puffs" per cylinder.
7. Take the compression test at each cylinder and record the readings.




Figure 1—Fuel Solenoid Wire

V0406




Figure 2—Checking Diesel Engine Compression

**NOTICE:** Do not add oil to any cylinder during a compression test as extensive engine damage can result.

8. The lowest reading cylinder should not be less than 80 percent of the highest reading cylinder. No cylinder should read less than 2625 kPa (380 psi).

- Normal: Compression builds up quickly and evenly to specified compression on each cylinder. Reading should be in the 2625-2760 kPa (380-400 psi) range.
- Leaking: Compression low on first stroke, tends to build up on following strokes, but does not reach normal.

### CRANKING SPEED TEST (6.5L DIESEL ENGINE)

Tool Required:

J 26999 Compression Gage

J 26999-10 Compression Gage

Cranking speed is critical for a diesel engine to start, either hot or cold. Some tachometers are not accurate at cranking speed. An alternate method of testing cranking speed or determining the accuracy of a tachometer follows:

1. Screw J 26999-10 into any cylinder and connect J 26999.

2. Disconnect the injection pump fuel solenoid lead on the top of the injection pump. See figure 1.
3. Install the digital tachometer to be tested (if desired).
4. Depress the pressure release valve on the compression gage.
5. With aid of an assistant, crank the engine for 2 or 3 seconds to allow the starter to reach full speed. Then, without stopping, count the number of "puffs" at the compression gage that occur in the next 10 seconds. Multiply the number of "puffs" in the 10 second period by 12 and the resulting number will be the engine speed.

Example:

10 seconds = 1/6 of a minute

1 puff = Engine speed of 2

Engine speed = No. of puffs x 2 x 6 or

Engine speed = No. of puffs x 12

Minimum cranking speed on the 6.5L diesel engine is 100 cold and 180 hot. The actual cranking speed needed will vary depending on the condition of the engine (compression) and nozzles.

### CAMSHAFT GEAR TIMING TEST

This procedure is a test for proper camshaft gear timing without removing the front cover of the engine.

#### ! Important

The following test will not work with the rocker arms on the heads because the valve spring pressure causes the hydraulic lifters to bleed down and not give true lobe lift readings. Also, it is important that the crankshaft is rotated only in a clockwise direction so that the timing chain slack does not effect the position of the maximum lobe lift.

#### ↔ Remove or Disconnect

1. All of the spark plugs (glow plugs on diesels).
2. Valve cover and rocker arms for the number 1 cylinder and mount a dial indicator on the exhaust pushrod to read camshaft exhaust lobe lift.
  - Rotate the crankshaft slowly clockwise until the dial indicator shows maximum exhaust lobe lift.
  - Place a chalk mark on the torsional damper (harmonic balancer) next to the timing tab.
  - Reposition the dial indicator over the intake pushrod and slowly rotate the crankshaft clockwise until maximum lobe lift is obtained.
  - Place a second chalk mark on the torsional damper (harmonic balancer) next to the timing tab.

- Measure the distance from each of the chalk marks to the factory timing groove in the torsional damper (harmonic balancer). If the camshaft gear is properly indexed (positioned) to the crankshaft gear, the distance of each chalk

mark to the factory gear timing groove (TDC) will be roughly the same. If the gears are out of position by one tooth or more, the distance from the chalk marks to the (TDC) mark will differ by roughly 50.8 mm (2 inches) or more.

## **DIAGNOSIS CHARTS**

### **DIESEL ENGINE DIAGNOSIS**

The diesel engine diagnosis charts cover the areas of mechanical/maintenance, electrical/emissions, and air system (figures 3, 4, 5, and 6).



# DIAGNOSIS OF DIESEL ENGINE

## MOST LIKELY/POSSIBLE CAUSES

**SYMPTOMS**

LOW LOSS OF POWER  
 HARD TO START  
 WILL NOT START-HOT  
 WILL NOT START-COLD  
 ENGINE STARTS-THEY STALLS  
 ROUGH/MISERIES OR BACKFIRES  
 ENGINE WON'T IDLE  
 POOR ACCELERATION  
 ENGINE SPEED SHUT-OFF  
 EXCESSIVE SPEED FLUCTUATES  
 BLACK SMOKE AT LOAD (HOT)  
 BLACK SMOKE AT IDLE  
 EXCESSIVE ACCELERATION SMOKE  
 GREY SMOKE  
 BLUE SMOKE  
 EXCESSIVE LUBE OIL CONSUMPTION  
 EXCESSIVE FUEL CONSUMPTION  
 FUEL OR LUBE OIL LEAKS  
 LUBE OIL CONTAMINATED  
 COOLANT CONTAMINATED  
 HIGH COOLANT TEMPERATURE  
 NO HEAT FROM HEATER  
 CRANKCASE SLUDGE  
 LOW OIL PRESSURE  
 HIGH OIL PRESSURE  
 HIGH CRANKCASE PRESSURE  
 HIGH INLET RESTRICTION  
 MECHANICAL KNOCKS  
 FUEL INCKAS RESTRICTION  
 EXCESSIVE ENGINE VIBRATION  
 SEIZED ENGINE COMPONENT  
 LOW CYLINDER COMPRESSION  
 ALL (Ø) GLOW PLUGS FAILED  
 (1) OR MORE GLOW PLUGS FAILED  
 RELAY WILL NOT CYCLE-GLOW PLUGS D.K.  
 GLOW PLUG SYSTEM AND LIGHT INOP.  
 WATER IN FUEL LIGHT ON/BLINKS

LUBRICATION	SYMPTOMS																																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40		
INTERNAL OIL LEAKS (BLOCK GALLERY/CUP PLUGS)																																										
LOW OIL LEVEL																																										
HIGH OIL LEVEL (OVER-FILLED)	●																																									
FAULTY REGULATOR OR BY-PASS-VALVE																																										
CONTAMINATED LUBE OIL																																										
HIGH LUBE OIL TEMPERATURE																																										
QUALITY/GRADE OF LUBE OIL	●			●																																						
INACCURATE GAGE OR SENSOR																																										
FAULTY OIL COOLER CORE																																										
FAULTY OIL PUMP DRIVE GEAR/SHAFT																																										
OIL PICKUP TUBE RESTRICTED/CRACK																																										
EXTERNAL OIL LEAKS ( PLUGS, SEALS OR GASKETS)																																										
FAULTY OIL PUMP																																										
COOLING	SYMPTOMS																																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40		
QUALITY/GRADE OF COOLANT																																										
LOW COOLANT LEVEL																																										
FAULTY OR INCORRECT PRESSURE CAP																																										
INACCURATE TEMPERATURE GAGE/SENSOR																																										
OBSTRUCTED RADIATOR AIR FLOW																																										
INOPERATIVE COOLANT PUMP																																										
FAULTY OPERATION OF FAN, VISCOUS CLUTCH/BELTS	●																																									
FAULTY THERMOSTAT																																										
FAULTY COOLANT RECOVERY SYSTEM																																										
RESTRICTED COOLANT FLOW																																										
AIR RECIRCULATION OR FAULTY FAN SHROUD																																										
FAULTY OR INADEQUATE DEAERATION SYSTEM/VENTS																																										
HIGH COOLANT TEMPERATURE																																										
LOW COOLANT TEMPERATURE																																										

**X = LIKELIEST CAUSES**  
**● = POSSIBLE CAUSES**

Figure 4—Diesel Engine Diagnosis (2 of 4)

V3343

DIAGNOSIS OF DIESEL ENGINE

MOST LIKELY/POSSIBLE CAUSES

- SYMPTOMS**
- 1. LOW/LOSS OF POWER
  - 2. HARD TO START
  - 3. WILL NOT START
  - 4. WILL NOT START-HOT
  - 5. ENGINE STARTS-COLD
  - 6. ENGINE STARTS-TREK STALLS
  - 7. ROUGH/ERRATIC OR RACIFRES
  - 8. ENGINE WON'T IDLE
  - 9. POOR ACCELERATION
  - 10. ENGINE SPEED SHUT-OFF
  - 11. EXCESSIVE SPEED FLUCTUATES
  - 12. BLACK SMOKE AT LOAD (HOT)
  - 13. BLACK SMOKE AT IDLE
  - 14. GREY SMOKE
  - 15. BLUE SMOKE
  - 16. EXCESSIVE LUBE OIL CONSUMPTION
  - 17. EXCESSIVE FUEL CONSUMPTION
  - 18. FUEL OR LUBE OIL LEAKS
  - 19. LUBE OIL CONTAMINATED
  - 20. COOLANT CONTAMINATED
  - 21. HIGH COOLANT TEMPERATURE
  - 22. NO HEAT FROM TEMPERATURE
  - 23. CRANKCASE B/LUDGE
  - 24. LOW OIL PRESSURE
  - 25. HIGH OIL PRESSURE
  - 26. HIGH CRANKCASE PRESSURE
  - 27. MECHANICAL RESTRICTION
  - 28. FUEL INJECTORS
  - 29. EXCESSIVE ENGINE VIBRATION
  - 30. LOW CYLINDER COMPONENT
  - 31. ALL (Ø) GLOW PLUGS FAILED
  - 32. (1) OR MORE GLOW PLUGS FAILED
  - 33. RELAY WILL NOT CYCLE-GLOW PLUGS FAILED
  - 34. GLOW PLUG SYSTEM AND LIGHT INOP.
  - 35. WATER IN FUEL LIGHT DIMBLINKS

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40								
GASKET BLOW-BY OR SEAL LEAKAGE	●								●		●				●		●	●			●	X	●		X				●																			
FAULTY DAMPER/FLYWHEEL BALANCE																																																
VALVE LEAKAGE	●	●	●	●		●	●		●		●	●					●	●																														
BROKEN, SCORED OR WORN PISTONS/RINGS	●	●	●	●		●			●		●	●																																				
INCORRECT MAIN OR ROD BEARING CLEARANCE																																																
DAMAGED CRANKSHAFT OR MAIN/ROD BEARINGS						●																																										
DAMAGED/WORN CAMSHAFT LOBES	●	●			●	●			●			●																																				
FAULTY LIFTER OR GUIDE PLATE	●				●	●					●																																					
FAULTY PUSHROD OR ROCKER ARM	●				●	●																																										
WORN/MISALIGNED TIMING GEARS, CHAIN OR KEY(S)	●				●	●																																										
LOW CYLINDER COMPRESSION (380 PSI MIN.)	●	●	X	●	●	●			●																																							
OIL CHANGE INTERVAL																	●				●																											
EXTERNAL INJECTION PUMP THROTTLE LINKAGE	●					●			●																																							
TIMING RETARDED	●	●		●	●	●			●		X				●																																	
TIMING ADVANCED	●	●		●	●	●						X	●																																			
STARTER CRANKING SPEED/BATTERIES (180 RPM MIN.)		●	X	●																																												
ENGINE MOUNTS/BOLTS OR FUEL LINE/OIL FILL TUBE CLAMPS																																																
LONG IDLE PERIODS											●	●		●																																		
CRACKED CYLINDER HEAD OR WALL																																																
MISSING PRECHAMBER(S)	●				●	●						●	●																																			
ENGINE OVERLOADED/EXCESSIVE SPEED	●								●			●	●				X	X										●																				
IMPROPER STARTING PROCEDURES		●		●																																												
DEBRIS/FLUID IN CYLINDER(S)																																																

X = LIKELIEST CAUSES  
 ● = POSSIBLE CAUSES

Figure 5—Diesel Engine Diagnosis (3 of 4)



## 6A-10 ENGINE, DRIVEABILITY, AND DIAGNOSIS

### DIAGNOSIS OF "SERVICE FUEL FILTER" LIGHT

PROBLEM	POSSIBLE CAUSE	CORRECTION
Intermittent Light	Water in fuel filter.	Drain water from the fuel filter.
Light Stays On With Engine Running (Temperature Above Freezing)	Fuel filter is clogged or contains water.	Drain the fuel filter. If no water is drained and the light stays on, replace the filter element.
Light Stays On With Engine Running (Temperature Below Freezing)	Fuel filter is clogged with ice.	Drain the fuel filter. If no water is drained, open the air bleed and check for fuel pressure. Replace the filter element if there is no pressure.
Light Comes On At High Speed Or During Heavy Acceleration	Plugged fuel filter.	Replace the filter element.
Light Stays On Continuously And Engine Stalls And Will Not Restart (After Initial Start-Up)	Fuel filter or lines plugged.	Replace the filter element or check the lines.
Light Stays On Continuously And Engine Stalls and Will Not Restart (After Refueling)	Large amounts of water pumped into the tank.	Purge the fuel tank.

D0250

### DIAGNOSIS OF NOISES

PROBLEM	POSSIBLE CAUSE	CORRECTION
High-Pitched Whine During Cranking (Before Engine Fires) But Engine Cranks And Fires Normally	Distance too great between starter pinion and flywheel.	Remove shims at the starter mount. Refer to SECTION 6D2.
High-Pitched Whine After The Engine Fires As Key Is Being Released. The Engine Cranks And Fires Normally. This Complaint Is Often Diagnosed As "Starter Hang-In" Or "Solenoid Weak".	Distance too small between starter pinion and flywheel. Flywheel runout contributes to the intermittent nature of the problem.	Add shims at the starter mount. Refer to SECTION 6D2.
A Loud "Whoop" After The Engine Fires But While The Starter Is Still Held Engaged. Sounds Like A Siren If The Engine Is Revved While The Starter Is Engaged.	Usually due to a worn starter motor clutch.	Remove the starter motor and check the starter clutch. Refer to the Light Duty Truck Unit Repair Manual.

**DIAGNOSIS OF NOISES (cont'd)**

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p><b>A "Rumble", "Growl", Or (In Severe Cases) A "Knock" As The Starter Is Coasting Down To A Stop After Starting The Engine</b></p>	<p>Usually due to a bent or unbalanced starter armature.</p>	<p>Remove the starter motor and check the armature. Refer to the Light Duty Truck Unit Repair Manual.</p>
<p><b>Engine Noisy On Initial Start Up But Only Lasts A Few Seconds</b></p>	<ol style="list-style-type: none"> <li>1. Hydraulic lifter bleed down. This condition is normal. Oil drains from the lifters, which are holding the valves open, when the engine is not running. It will take a few seconds for the lifter to fill after the engine is started.</li> <li>2. Improper oil viscosity.</li> </ol>	<ol style="list-style-type: none"> <li>1. None needed.</li> <li>2. Install proper oil viscosity for expected temperatures. Refer to Owner's Manual.</li> </ol>
<p><b>Intermittently Noisy On Idle Only, Disappearing When Engine Speed Is Increased.</b></p>	<ol style="list-style-type: none"> <li>1. Dirt in hydraulic lifter.</li> <li>2. Pitted or damaged lifter check ball.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace the hydraulic lifter.</li> <li>2. Replace the hydraulic lifter.</li> </ol>
<p><b>Engine Knocks Cold And Continues For Two To Three Minutes. Knock Increases With Torque</b></p>	<ol style="list-style-type: none"> <li>1. Flywheel contacting splash shield.</li> <li>2. Loose or broken torsional damper or drive pulleys.</li> <li>3. Excessive piston to bore clearance.</li> <li>4. Bent connecting rod.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reposition splash shield.</li> <li>2. Tighten or replace as necessary.</li> <li>3. Replace piston; inspect bore.</li> <li>4. Replace connecting rod.</li> </ol>
<p><b>Noisy At Idle, Becoming Louder As Engine Speed Is Increased To 1500 RPM</b></p>	<ol style="list-style-type: none"> <li>1. This noise is not connected to hydraulic valve lifter malfunction. It becomes most noticeable in the vehicle at 10 to 15 mpg in "L" (Low) range, or 30 to 35 mph in "D" (Drive) range and is best described as a "ticking" sound. At slow idle, it may be entirely gone or appear as a light ticking noise in one or more valves. It is caused by one or more of the following: <ul style="list-style-type: none"> <li>• Badly worn or scuffed valve tip and rocker arm pad</li> <li>• Excessive valve stem to guide clearance.</li> <li>• Excessive valve seat runout.</li> <li>• Off-square valve spring.</li> <li>• Excessive valve face runout.</li> <li>• Valve spring damper clicking on rotator.</li> </ul> </li> <li>2. Off-square valve spring. Occasionally this noise can be eliminated by rotating the valve spring and valve. Crank engine until noisy valve is off its seat. Rotate spring. This will rotate valve. Repeat until valve is quiet. If correction is obtained, Check for off-square valve spring.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair as necessary.</li> <li>2. If the valve spring is more than 1.6 mm (1/16 inch) off-square, it should be replaced.</li> </ol>

**DIAGNOSIS OF NOISES (cont'd)**

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p>Noisy At Slow Idle Or With Hot Oil; Quiet At Higher Engine Speeds Or with Cold Oil</p>	<p>High hydraulic lifter leak down rate.</p>	<p>Replace the hydraulic lifter.</p>
<p>Engine Knocks At Idle Hot</p>	<ol style="list-style-type: none"> <li>1. Loose or worn drive belts.</li> <li>2. Air conditioning compressor or generator bearing.</li> <li>3. Valve train.</li> <li>4. Improper oil viscosity.</li> <li>5. Excessive piston pin clearance.</li> <li>6. Connecting rod alignment.</li> <li>7. Insufficient piston to bore clearance. (Cold engine piston knock usually disappears when the cylinder's spark plug wire is grounded out. Cold engine piston knock which disappears in 1.5 minutes should be considered acceptable.)</li> <li>8. Loose torsional damper.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tension and/or replace as necessary.</li> <li>2. Replace as necessary.</li> <li>3. Refer to "Valve Train Noise" in this chart.</li> <li>4. Install proper oil viscosity for expected temperatures. Refer to Owner's Manual.</li> <li>5. Install new piston, pin and/or connecting rod as needed.</li> <li>6. Check and replace rods as necessary.</li> <li>7. Hone cylinder and fit new piston, if required.</li> <li>8. Torque damper or replace worn parts.</li> </ol>
<p>Noisy At High Vehicle Speeds, Quiet At Low Speeds</p>	<ol style="list-style-type: none"> <li>1. High oil level—Oil level above the "Full" mark allows crankshaft counterweights to churn the oil into foam. When foam is pumped into the lifters, they will become noisy since a solid column of oil is required for proper operation.</li> <li>2. Low oil level—Oil level below the "Add" mark allows the oil pump to pump air at high speeds, which results in noisy lifters.</li> <li>3. Oil pan bent against oil pump pickup screen.</li> <li>4. Oil pump pickup screen bent or loose.</li> </ol>	<ol style="list-style-type: none"> <li>1. Drain oil to proper level.</li> <li>2. Add oil as needed.</li> <li>3. Repair.</li> <li>4. Repair.</li> </ol>
<p>Noisy Regardless Of Engine Speed</p>	<ol style="list-style-type: none"> <li>1. Incorrect valve adjustment (excessive lash) (engines with adjustable valve lash.)</li> <li>2. Excessive valve lash. Check for valve lash by turning the engine so that the piston in that cylinder is on TDC of the firing stroke. If valve lash is present, the pushrod can be freely moved up and down a certain amount with the rocker arm held against the valve. Excessive lash can be caused by:             <ol style="list-style-type: none"> <li>a. Worn pushrod upper end ball.</li> <li>b. Bent pushrod.</li> <li>c. Improper lubrication of the pushrod.</li> </ol> </li> <li>d. Loose or damaged rocker arm.</li> <li>e. If pushrod and rocker arm are OK, trouble in the hydraulic lifter is indicated.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust as specified.</li> <li>2. Repair engine as needed.             <ol style="list-style-type: none"> <li>a. Replace pushrod and rocker arm.</li> <li>b. Replace pushrod.</li> <li>c. Replace pushrod and rocker arm. Check lubrication system feed to the pushrod.</li> <li>d. Replace rocker arm.</li> <li>e. Replace hydraulic lifter.</li> </ol> </li> </ol>

**DIAGNOSIS OF NOISES (cont'd)**

PROBLEM	POSSIBLE CAUSE	CORRECTION
<b>Engine Has Light Knock Hot In Light Load Conditions</b>	<ol style="list-style-type: none"> <li>1. Faulty Ignition Control or Knock Sensor Circuit system.</li> <li>2. Improper timing.</li> <li>3. Poor quality fuel.</li> <li>4. EGR valve malfunction.</li> <li>5. Loose torque converter bolts.</li> <li>6. Exhaust leak at manifold.</li> <li>7. Excessive rod bearing clearance.</li> </ol>	<ol style="list-style-type: none"> <li>1. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>2. Adjust to specifications.</li> <li>3. Use fuel of recommended grade.</li> <li>4. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>5. Tighten bolts.</li> <li>6. Tighten bolts and/or replace gaskets.</li> <li>7. Replace bearings as necessary.</li> </ol>
<b>Engine Has Heavy Knock Hot With Torque Applied</b>	<ol style="list-style-type: none"> <li>1. Broken balancer or pulley hub.</li> <li>2. Loose torque converter bolts.</li> <li>3. Accessory belts too tight or nicked.</li> <li>4. Exhaust system touching vehicle.</li> <li>5. Flywheel cracked or loose flywheel rivets.</li> <li>6. Excessive main bearing clearance.</li> <li>7. Excessive rod bearing clearance.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace parts as necessary.</li> <li>2. Tighten bolts.</li> <li>3. Replace and/or tension to specs. as necessary.</li> <li>4. Reposition as necessary.</li> <li>5. Replace flywheel.</li> <li>6. Repair as necessary.</li> <li>7. Repair as necessary.</li> </ol>
<b>Valve Train Noise</b>	<ol style="list-style-type: none"> <li>1. Low oil pressure.</li> <li>2. Loose rocker arm attachments.</li> <li>3. Worn rocker arm and/or pushrod.</li> <li>4. Broken valve spring.</li> <li>5. Sticking valves.</li> <li>6. Lifters worn, dirty, or faulty.</li> <li>7. Camshaft worn or faulty.</li> <li>8. Worn valve guides.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair as necessary. (Refer to diagnosis for "Low Oil Pressure" in previous chart).</li> <li>2. Inspect as necessary.</li> <li>3. Replace as necessary.</li> <li>4. Replace spring.</li> <li>5. Free valves.</li> <li>6. Refer to other hydraulic lifter-related causes and corrections in this chart.</li> <li>7. Replace camshaft.</li> <li>8. Repair as necessary.</li> </ol>
<b>Vibrating Or Rattling From Exhaust System</b>	Loose and/or misaligned exhaust components.	Align, then tighten connections. Check for damaged hangers or mounting brackets and clamps.
<b>Exhaust Leakage And/Or Noise</b>	<ol style="list-style-type: none"> <li>1. Leakage at exhaust component joints and couplings.</li> <li>2. Improperly installed or misaligned exhaust system.</li> <li>3. Exhaust manifold cracked or broken.</li> <li>4. Leak between exhaust manifold or cylinder head.</li> <li>5. Damaged or worn exhaust seals or packing.</li> <li>6. Burned or rusted out exhaust pipe heat tube extension.</li> <li>7. Burned or rusted out exhaust pipe.</li> <li>8. Burned or blown out muffler.</li> <li>9. Broken or loose exhaust clamps and/or brackets.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten clamps or couplings to specified torque.</li> <li>2. Align, then tighten connections.</li> <li>3. Replace the manifold.</li> <li>4. Tighten the manifold to cylinder head nuts and bolts to specifications.</li> <li>5. Replace the seals or packings as necessary.</li> <li>6. Replace the heat tube extensions as required.</li> <li>7. Replace the exhaust pipe.</li> <li>8. Replace the muffler assembly.</li> <li>9. Repair or replace as necessary.</li> </ol>

**DIAGNOSIS OF POWER PROBLEMS**

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p><b>Engine Hesitates During Normal Acceleration</b></p> <p><b>Hesitates During Cold Engine Operation</b></p>	<ol style="list-style-type: none"> <li>1. Engine Control Module malfunction.</li> <li>2. Ignition timing misadjusted.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>2. Adjust timing. Refer to Emission Control Information Label on vehicle.</li> </ol>
<p><b>Engine Has Less Than Normal Power At Normal Acceleration</b></p>	<ol style="list-style-type: none"> <li>1. Ignition system malfunction.</li> <li>2. Ignition timing misadjusted.</li> <li>3. Plugged air cleaner element.</li> <li>4. Exhaust system restricted.</li> <li>5. Engine Control Module malfunction.</li> <li>6. Transmission malfunction.</li> <li>7. Fuel filter(s) partially plugged.</li> <li>8. Faulty fuel pump, or leaking or restricted fuel lines.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check ignition system. Refer to SECTION 6D4.</li> <li>2. Adjust timing. See Emission Control Information Label on vehicle.</li> <li>3. Replace element.</li> <li>4. Check for restrictions. See diagnosis for "Restricted Exhaust System" in this chart.</li> <li>5. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>6. Refer to SECTION 7.</li> <li>7. Inspect fuel filter(s). Replace as necessary.</li> <li>8. Check fuel pump pressure and volume. Replace pump if necessary. Inspect fuel lines for leaks and restrictions.</li> </ol>
<p><b>Less Than Normal Power On Heavy Acceleration Or At High Speed</b></p>	<ol style="list-style-type: none"> <li>1. Ignition system malfunction.</li> <li>2. Ignition timing misadjusted.</li> <li>3. Plugged air cleaner element.</li> <li>4. Exhaust system restricted.</li> <li>5. Engine Control Module malfunction.</li> <li>6. Transmission malfunction.</li> <li>7. Fuel filter(s) partially plugged.</li> <li>8. Faulty fuel pump or leaking or restricted fuel lines.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check ignition system. Refer to SECTION 6D4.</li> <li>2. Adjust timing. See Emission Control Information Label on vehicle.</li> <li>3. Replace element.</li> <li>4. Check for restrictions. See diagnosis for "Restricted Exhaust System" in this chart.</li> <li>5. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>6. Refer to SECTION 7.</li> <li>7. Inspect fuel filter(s). Replace as necessary.</li> <li>8. Check fuel pump pressure and volume. Replace fuel pump if necessary. Inspect fuel lines for leaks and restrictions.</li> </ol>
<p><b>Engine Surges</b></p>	<ol style="list-style-type: none"> <li>1. Ignition system malfunction.</li> <li>2. Exhaust system restricted.</li> <li>3. Engine Control Module malfunction.</li> <li>4. Contaminated fuel.</li> <li>5. Fuel filter(s) partially plugged.</li> <li>6. Faulty fuel pump or leaking or restricted fuel lines.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check ignition system. Refer to SECTION 6D4.</li> <li>2. Check for restrictions. Correct as necessary. See diagnosis for "Restricted Exhaust System" in this chart.</li> <li>3. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>4. Check for water or excessive alcohol in fuel.</li> <li>5. Inspect fuel filter(s). Replace as necessary.</li> <li>6. Check fuel pump pressure and volume. Replace pump if necessary. Inspect fuel lines for leaks and restrictions.</li> </ol>

**DIAGNOSIS OF POWER PROBLEMS (cont'd)**

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>CORRECTION</b>
<b>Fuel Starvation</b>	<ol style="list-style-type: none"> <li>1. Fuel filter(s) plugged.</li> <li>2. Fuel lines leaking, restricted or mis-routed.</li> <li>3. Faulty fuel pump.</li> </ol>	<ol style="list-style-type: none"> <li>1. Inspect fuel filter(s). Replace as necessary.</li> <li>2. Repair/replace, clean, or reroute as required.</li> <li>3. Check fuel pump pressure and volume. Replace pump if necessary.</li> </ol>
<b>Restricted Exhaust System</b>	<ol style="list-style-type: none"> <li>1. "Kinked" exhaust tubing.</li> <li>2. Restriction inside the muffler.</li> <li>3. End of tail pipe obstruction.</li> <li>4. Plugged three way catalytic converter (may result from serious engine malfunction).</li> </ol>	<ol style="list-style-type: none"> <li>1. If possible, repair the damaged condition, otherwise replace the component.</li> <li>2. If restriction is suspected, remove the muffler and visually check it. Replace muffler if condition is doubtful.</li> <li>3. Remove the obstruction, or if end is crimped, straighten outlet.</li> <li>4. Replace the three way catalytic converter.</li> </ol>

D0263

**DIAGNOSIS OF STARTING/IDLING/SHUTOFF PROBLEMS**

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>CORRECTION</b>
<b>Engine Will Not Turn Over</b>	<ol style="list-style-type: none"> <li>1. Battery, cranking system, or other electrical problem.</li> <li>2. Liquid in combustion chamber.</li> <li>3. Seized engine.</li> </ol>	<ol style="list-style-type: none"> <li>1. Refer to SECTION 6D2.</li> <li>2. Remove with suction gun.</li> <li>3. Repair.</li> </ol>
<b>Engine Cranks Normally—Will Not Start Or Starts Hard</b>	<ol style="list-style-type: none"> <li>1. Improper starting procedure used.</li> <li>2. Ignition system malfunction.</li> <li>3. Engine loaded with fuel. (Improper starting procedure used).</li> <li>4. No fuel.</li> <li>5. Restricted exhaust system.</li> <li>6. Low compression due to stuck or burned valves, sticking piston rings, blown head gasket, etc.</li> <li>7. Engine Control Module malfunction.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check with the customer to determine if proper starting procedure, outlined in the Owner's Manual, is used.</li> <li>2. Check ignition system. Refer to SECTION 6D4.</li> <li>3. Check with the customer to determine if proper starting procedure, outlined in Owner's Manual, is used.</li> <li>4. Inspect fuel filter(s) for plugging. Replace as necessary. Check fuel pump pressure and volume. Replace pump if necessary. Inspect fuel lines for leaks and restrictions.</li> <li>5. Repair. Refer to diagnosis for "Restricted Exhaust system" in "Power Problems" chart.</li> <li>6. Perform a compression test, as outlined in this section. Repair engine as necessary.</li> <li>7. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> </ol>

**DIAGNOSIS OF STARTING/IDLING/SHUTOFF PROBLEMS (cont'd)**

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p><b>Engine Starts—Will Not Keep Running</b></p>	<ol style="list-style-type: none"> <li>1. Air leaks at intake manifold gasket. Vacuum hoses disconnected or installed improperly.</li>   <li>2. Not enough fuel.</li>   <li>3. Engine Control Module malfunction.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use a pressure oil can to spray light oil or kerosene around manifold to head mounting surfaces. If engine RPM changes, torque intake manifold bolts to specification. If necessary, replace the intake manifold gasket(s). Check condition and routing of vacuum hoses. Correct or replace as necessary. Refer to Emission Control Information Label on vehicle for correct routing.</li> <li>2. Inspect fuel filter(s) for being partially plugged. Replace as necessary. Check fuel pump pressure and volume. Replace pump if necessary. Inspect fuel lines for leaks and restrictions.</li> <li>3. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> </ol>
<p><b>Engine Idles Abnormally (Too Fast Or Too Slow)</b></p>	<ol style="list-style-type: none"> <li>1. Engine Control Module malfunction.</li>   <li>2. Throttle linkage or throttle shaft sticking or binding.</li>   <li>3. Air leaks at intake manifold gasket, Vacuum hoses disconnected or improperly installed.</li>   <li>4. Restricted air cleaner element.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>2. Check throttle linkage and throttle shaft(s) for smooth and free operation. Clean with suitable solvent. Replace throttle body if necessary.</li> <li>3. Use a pressure oil can to spray light oil or kerosene around manifold to head mounting surfaces. If engine RPM changes, torque intake manifold bolts to specification. If necessary, replace the intake manifold gasket(s). Check condition and routing of vacuum hoses. Correct or replace as necessary. Refer to Emission Control Information Label on vehicle for correct routing.</li> <li>4. Replace if necessary.</li> </ol>
<p><b>Rough Idle</b></p>	<ol style="list-style-type: none"> <li>1. Engine Control Module malfunction.</li>   <li>2. Uneven cylinder compression.</li>   <li>3. Bent pushrod or broken valve spring.</li> <li>4. Faulty engine mount.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>2. Perform a compression test, as outlined in this section. Repair engine as necessary.</li> <li>3. Repair.</li> <li>4. Repair or replace.</li> </ol>

**DIAGNOSIS OF STARTING/IDLING/SHUTOFF PROBLEMS (cont'd)**

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p><b>Engine Diesels (After Run) Upon Shut Off</b></p>	<ol style="list-style-type: none"> <li>1. Air leaks at intake manifold gasket(s). Vacuum hoses disconnected or improperly installed.</li>   <li>2. PCV system malfunctioning.</li>   <li>3. Ignition timing retarded (causes throttle valve to be opened farther than normal to obtain correct idle speed).</li>   <li>4. Engine Control Module malfunction.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use pressure oil can to spray light oil or kerosene around manifold to head mounting surfaces. If engine RPM changes, torque intake manifold bolts to specification. If necessary, replace the intake manifold gasket(s). Check condition and routing of vacuum hoses. Correct or replace as necessary. Refer to Emission Control Information Label for correct routing.</li> <li>2. Check PCV system. Clean or replace PCV valves and hoses as necessary.</li> <li>3. Adjust timing. See Emission Control Information Label.</li>   <li>4. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> </ol>

D0265

## DIAGNOSIS OF POOR FUEL ECONOMY/SMOKE/OIL/ODORS

PROBLEM	POSSIBLE CAUSE	CORRECTION
<b>Poor Gas Mileage</b> <b>*Black Smoke From Tail Pipe</b>	<ol style="list-style-type: none"> <li>1. Customer driving habits.</li> <li>2. Wrong speedometer gear.</li> <li>3. Low tire pressure or incorrect tire size.</li> <li>4. Transmission malfunction or in wrong gear.</li> <li>5. Fuel leaks.</li> <li>6. Plugged air cleaner element.</li> <li>7. Ignition system malfunction.</li> <li>8. Ignition timing misadjusted.</li> <li>9. Engine Control Module malfunction.</li> <li>10. Air leaks at intake manifold gasket. Vacuum hoses disconnected or improperly installed.</li> <li>11. Engine in need of service</li> <li>12. Restricted exhaust system.</li> </ol>	<ol style="list-style-type: none"> <li>1. Run mileage test, with customer driving if possible. Make sure engine has at least 2,000-3,000 miles (3,200-4,800 km) for the "break-in" period.</li> <li>2. Check odometer against measured mile. Replace speedometer gear if necessary. Refer to SECTION 7.</li> <li>3. Inflate tires to specifications and use correct tire sizes. Refer to label on driver's door.</li> <li>4. Refer to SECTION 7.</li> <li>5. Inspect fuel tank, fuel lines and fuel pump for any fuel leakage.</li> <li>6. Replace element.</li> <li>7. Check ignition system. Refer to SECTION 6D4.</li> <li>8. Adjust timing. Refer to Emission Control Information Label.</li> <li>9. Check operation. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>10. Use a pressure oil can to spray light oil or kerosene around manifold to head mounting surfaces. If engine RPM changes, torque intake manifold bolts to specification. If necessary, replace the intake manifold gasket(s). Check condition and routing of vacuum hoses. Correct or replace as necessary. Refer to Emission Control Information Label on vehicle for correct routing.</li> <li>11. Check engine compression.</li> <li>12. Check for restrictions and correct as necessary.</li> </ol>
<b>Low Oil Pressure</b>	<ol style="list-style-type: none"> <li>1. Incorrect or faulty oil pressure switch or sensor.</li> <li>2. Incorrect or faulty oil pressure gage.</li> <li>3. Improper oil viscosity.</li> <li>4. Diluted engine oil.</li> <li>5. Oil pump worn or dirty.</li> <li>6. Plugged oil filter.</li> <li>7. Oil pickup screen loose or plugged.</li> <li>8. Hole in oil pickup tube.</li> <li>9. Excessive bearing clearance.</li> <li>10. Cracked, porous or plugged oil galleries</li> <li>11. Oil gallery plugs missing or mis-installed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace with correct/new switch or sensor.</li> <li>2. Replace with correct/new gage.</li> <li>3. Replace with proper oil. Refer to Owner's Manual.</li> <li>4. Change engine oil and filter. Repair cause of dilution (rich mixture, etc.).</li> <li>5. Clean pump and replace worn parts as necessary.</li> <li>6. Replace filter and oil.</li> <li>7. Clean or replace screen as necessary.</li> <li>8. Replace pickup tube.</li> <li>9. Replace as necessary.</li> <li>10. Repair or replace block.</li> <li>11. Install plugs or repair as necessary.</li> </ol>
<b>Blue Smoke</b>	Usually caused by oil burning in the combustion chambers.	Refer to diagnosis for "Excessive Oil Loss" in this chart.

## DIAGNOSIS OF POOR FUEL ECONOMY/SMOKE/OIL/ODORS (cont'd)

PROBLEM	POSSIBLE CAUSE	CORRECTION
<b>White Smoke</b>	Usually caused by water vapor, which is a normal by-product of combustion. Usually seen on cold days.	None required.
<b>Excessive Oil Loss</b>	<ol style="list-style-type: none"> <li>1. Improper reading of dipstick.</li> <li>2. External oil leaks.</li> <li>3. Improper oil viscosity.</li> <li>4. Continuous high speed driving and/or severe usage.</li> <li>5. Crankcase ventilation or PCV system malfunction.</li> <li>6. Valve guides and/or valve stem seals worn, or seals missing.</li> <li>7. Piston rings not seated.</li> <li>8. Broken or worn piston rings.</li> <li>9. Piston improperly installed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check oil with vehicle on a level surface and allow adequate drain down time.</li> <li>2. Tighten bolts and/or replace gaskets and seals as necessary.</li> <li>3. Use recommended viscosity for prevailing temperature. Refer to Owner's Manual.</li> <li>4. Continuous high speed operation and/or severe usage will normally cause decreased oil mileage.</li> <li>5. Check PCV system. Clean or replace PCV valves and hoses as necessary.</li> <li>6. Ream guides and install oversize service valves and/or new valve stem seals.</li> <li>7. Allow adequate time for rings to seat.</li> <li>8. Replace broken or worn rings as necessary.</li> <li>9. Replace piston or repair as necessary.</li> </ol>
<b>Gasoline Odor</b>	<ol style="list-style-type: none"> <li>1. Fuel feed, fuel return, or vapor return line leaking.</li> <li>2. Leak in fuel tank.</li> <li>3. Disconnected or leaking fuel tank vent lines or hoses to canister(s).</li> <li>4. Purge lines not connected, improperly routed, plugged or pinched.</li> <li>5. Evaporative Emission Control System carbon canister(s) loaded.</li> <li>6. Faulty fuel tank fill cap.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair/replace as required. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>2. Purge tank and repair or replace tank as required. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>3. Connect, repair or replace lines as required. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>4. Connect, clean or reroute lines as required. Refer to Emission Control Information Label on vehicle for correct routing.</li> <li>5. Compare weight of canister with a new one. Replace if necessary. Refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.</li> <li>6. Install new fuel filler cap. Be sure to use a cap designed for gasoline and evaporation systems.</li> </ol>

**DIAGNOSIS OF SPARK PLUGS**

PROBLEM	POSSIBLE CAUSE	CORRECTION
Brown to Grayish-Tan Deposits And Slight Electrode Wear.	Normal wear.	Clean, regap, reinstall.
Dry, Fluffy Black Carbon Deposits.	Poor ignition system output.	Check the distributor to coil connections, as discussed in SECTION 6D4 or refer to the Driveability, Emissions, and Electrical Diagnosis Manual for this model.
Wet, Oily Deposits With Very Little Electrode Wear.	<ol style="list-style-type: none"> <li>1. "Break-in" of new or recently overhauled engine.</li> <li>2. Excessive valve stem to guide clearance.</li> <li>3. Worn intake valve seals.</li> </ol>	<ol style="list-style-type: none"> <li>1. Degrease, clean, and reinstall the plugs.</li> <li>2. Refer to specific engine section for procedure.</li> <li>3. Replace the seals.</li> </ol>
Red, Brown, Yellow and White Colored Coatings on Insulator. Engine Misses Intermittently Under Severe Operating Conditions.	By-products of combustion.	Clean, regap, and reinstall. If heavily coated, replace.
Colored Coatings Heavily Deposited on the Portion of the Plug Projecting into the Chamber and on the Side Facing the Intake Valve.	Leaking seals if condition is found in only one or two cylinders.	Check the seals. Replace if necessary. Clean, regap, and reinstall the plugs.

D0264

**OIL LEAK DIAGNOSIS**

Most oil leaks are easily located and repaired by visually finding the leak and replacing or repairing the necessary parts. On some occasions a fluid leak may be difficult to locate or repair. The following procedure may help in locating and repairing most leaks.

**FINDING THE LEAK**

1. Identify the fluid, determine whether it is engine oil, automatic transmission fluid, power steering fluid, etc.
2. From what point is the fluid leaking? After running the vehicle at normal operating temperature, park the vehicle over a large sheet of paper. After a few minutes, you should be able to find the approximate location of the leak by the drippings on the paper.
3. Visually check around the suspected component. Check around all gasket mating surfaces for leaks. Use a mirror for finding leaks that are hard to reach.
4. If the leak still cannot be found, it may be necessary to clean the suspected area with a degreaser, steam, or spray solvent. Clean the area, then dry

the area. Operate the vehicle for several miles at normal operating temperature and varying speeds. After operating the vehicle, visually check the suspected component. If you still cannot find the leak, try using the powder or black light and dye method.

**Powder Method**

1. Clean the suspected area.
2. Apply an aerosol-type powder (such as foot powder) on the suspected area.
3. Drive the vehicle under normal operating conditions.
4. Visually inspect the suspected component. You should be able to trace the leak path over the white powder surface to the source.

**Black Light and Dye Method**

A dye and light kit is available for finding leaks. Refer to the manufacturer's directions when using the kit.

1. Pour specified amount of dye into leaking component.
2. Drive the vehicle under normal operating conditions as directed in the kit.
3. Direct the light toward the suspected area. The dyed fluid will appear as a yellow path leading to the source.

## REPAIRING THE LEAK

Once the leak has been pinpointed and traced back to its source, the cause of the leak must be determined in order for it to be repaired properly. If a gasket is replaced, but the sealing flange is bent, the new gasket will not repair the leak. The bent flange must also be repaired. Before attempting to repair a leak, make sure the following conditions are correct as they may cause a leak.

### Gasket Leaks

Check for:

- High fluid level or high oil pressure.
- Plugged ventilation filter or valve.
- Improperly tightened fasteners or dirty/damaged threads.
- Warped flanges or sealing surface.


- Scratches, burrs, or other damage to the sealing surface.
- Damaged or worn gasket.
- Cracking or porosity of the component.
- Improper sealant, or no sealant where required.

### Seal Leaks

Check for:

- High fluid level or high oil pressure.
- Plugged ventilation filter, or valve.
- Damaged seal bore (scratched, burred, or nicked).
- Damaged or worn seal.
- Improper installation.
- Cracks in component.
- Shaft surface scratched, nicked, or damaged.
- Loose or worn bearing causing excess seal wear.

## SPECIAL TOOLS



**NOTES**

1. Check for proper  
operation of the  
air conditioning  
system. If the  
system is not  
operating, the  
engine will  
run hot and  
the compressor  
will be noisy.  
2. Check for proper  
operation of the  
power windows.  
If the windows  
do not operate  
properly, the  
engine will  
run hot and  
the windows  
will be noisy.  
3. Check for proper  
operation of the  
power locks.  
If the locks do  
not operate  
properly, the  
engine will  
run hot and  
the locks will  
be noisy.

